



Getting Started: Channel Settings for your System

To ensure that you have everything you need to **Get Started** please refer to the following checklist:

- **ExpressVu** TV for condos set-top box
- Primary **ExpressVu** remote
- Secondary **ExpressVu** remote(s)
- **IR Blaster** Kit

At the location where your set-top box is located, your TV and VCR should both be set to channel 3 or 4.

At each additional location, your TV and VCR should both be set to either 8, 12 or 13. Refer to the chart below or the sticker on the back of your remote for channel setting details.

Refer to:	Toronto Area	Ottawa Area	Montreal Area
TV1 and VCR1	3 or 4	3	3
TV2 and VCR2	8	8	8
TV3 and VCR3	13	12	13