



Bell SmartTouch™ Features

A selection of Bell **SmartTouch** services are linked to your TV. Here's an overview of how they work.


CALL DISPLAY

If you subscribe to a **Call Display** service, you can activate a **Caller ID** pop-up window that identifies the name and number of inbound calls on your TV screen*.

To clear the **Caller ID** pop-up window from your TV screen, scroll to **EXIT** and press **SELECT**.

TO ACTIVATE AND ADJUST THE CALLER ID DISPLAY TIME:

1. Press **MENU** on your remote
2. Select **TELEPHONE SERVICES**
3. Select **CALLER ID SETUP**. From this screen you can turn **Caller ID** on or off and set **CALLER ID DISPLAY TIME**
4. Follow the on screen prompts



* Set-top box supports on screen **Call Display** and **Call Answer** as provided by your local wireline telephone provider. Some names and/or numbers may not be displayed.

Bell SmartTouch Features



CALLER ID LOG

TO VIEW THE **CALLER ID LOG** IN THE TELEPHONE SERVICES MENU:

1. Press **MENU** on your remote
2. Select **TELEPHONE SERVICES**
3. Select **CALLER ID LOG**
4. The 50 most recent calls will be displayed



CALL ANSWER

If you subscribe to a **Call Answer** service, you can activate a **MESSAGE WAITING** pop-up window that will appear on your TV screen when you have a new voice-mail message and will read *You have voice-mail*. The **Call Answer** pop-up window will continue to re-appear until you listen to the message.

To temporarily clear the **Call Answer** pop-up window that appears, scroll to the **EXIT** option and press **SELECT**.



TO ACTIVATE/ADJUST THE **CALL ANSWER DISPLAY TIME**:

1. Press **MENU** on your remote
2. Select **TELEPHONE SERVICES**
3. Select **VOICE-MAIL SETUP**
4. Select **SET VOICE-MAIL DISPLAY TIME** or **TURN VOICE-MAIL ON/OFF**
5. Follow the on screen prompts

